



**NOVO U PONUDI!**

## Alu ljestve **KRAUSE® "Sibilo"**



Šifra	Opis
Z121387	Alu ljestve KRAUSE® „Sibilo“ 6 gazišta
Z120519	Alu ljestve KRAUSE® „Sibilo“ 9 gazišta
Z129109	Alu ljestve KRAUSE® „Sibilo“ 12 gazišta

# Alu dvostruke ljestve **KRAUSE® "Dubilo"**




Šifra	Opis
Z129475	Alu ljestve KRAUSE® „Dubilo“ 2x9 gazišta
Z129505	Alu ljestve KRAUSE® „Dubilo“ 2x12 gazišta



# Alu klizne ljestve **KRAUSE® "Fabilo"**



Šifra	Opis
Z129277	Alu ljestve KRAUSE® „Fabilo“ 2x9 gazišta
Z129307	Alu ljestve KRAUSE® „Fabilo“ 2x12 gazišta



# Alu višenamjenske podesive ljestve **KRAUSE® "Tribilo"**



Šifra	Opis
Z129741	Alu višenamjenske podesive ljestve KRAUSE® „Tribilo“ 3x8 gazišta
Z129765	Alu višenamjenske podesive ljestve KRAUSE® „Tribilo“ 3x10 gazišta
Z129789	Alu višenamjenske podesive ljestve KRAUSE® „Tribilo“ 3x12 gazišta



## Alu trodjelne ljestve **KRAUSE® "Tribilo"**




Šifra	Opis
Z129673	Alu trodjelne ljestve KRAUSE® „Tribilo“ 3x9 gazišta
Z129680	Alu trodjelne ljestve KRAUSE® „Tribilo“ 3x10 gazišta
Z129703	Alu trodjelne ljestve KRAUSE® „Tribilo“ 3x12 gazišta





# Alu univerzalne zglobne ljestve **KRAUSE® "Multimatic"**



Šifra	Opis
Z120687	Alu univerzalne zglobne ljestve KRAUSE® „Multimatic“ 4x3 gazišta sa platformom



Šifra	Opis
Z120694	Alu univerzalne zglobne ljestve KRAUSE® „Multimatic“ 4x4 gazišta



Šifra	Opis
Z122247	"Multimatic" čelična platforma

**LORENČIĆ-CROATIA d.o.o.**

## Glavno sjedište Zagreb

Bani 96 – Buzin  
10010 Zagreb

T: +385 1 66 08 210  
F: +385 1 66 08 212  
zagreb@lorencic.hr

## Solin

Zoranićeva 1a  
21210 Solin

T: +385 21 797 720  
F: +385 21 797 719  
solin@lorencic.hr

## Rijeka

Marinčić 177 (Poslovna zona Viškovo)  
51216 Viškovo

T: +385 51 682 262  
F: +385 51 682 292  
rijeka@lorencic.hr